Name	5. WALL: Knee Wall w/ 0.75" Air Gap			
Date	04-20-2021			
Section Schematic				
Layers/R- values	Layer Name	R-value of Assembly	R-value of Quattro Application	Notes
	QUATTRO Ultra-Thin Reflective Insulation	1.63	1.63	
	0.75″ Air Gap	2.84	2.84	(2) 0.75 Air Space @ 50/30 Vert. Horiz. (2.91+2.77)/2
	R-13 Batt Insulation	13		
	Interior Gypsum Board (5/8")	0.56		(1)
	Total	18.03	4.47	
R-Value of Quattro Application	4.47 [h.ft².F /Btu]			
Notes/ Reference	 Nail 1"x2" furring strip to the backs of each stud. Staple QUATTRO to the back face of the furring strip and staple downward every 3-4". Run QUATTRO parallel to studs. Furring strip will allow for 0.75" air gap between QUATTRO and fiberglass insulation. Keep a continuous 0.5" air gap along the bottom of the cavity. Install fiberglass insulation, following local codes and manufacturer's instructions. 			